



Micro Desktop Monitor Mount







IMPORTANT INFORMATION

- ! Please ensure this product is installed as per these installation instructions.
- ! This product is compatible with the range of AF Poles and arms.
- ! The manufacturer accepts no responsibility for incorrect installation.
- ! Curved monitors, deep devices (such as all-in-one PCs) and offset VESA locations exert additional leverage that can exceed the capacity of the mount even though the monitor weight may be within the stated range. Please contact Atdec if you would like further information.


1. Desk overview



2. How to reconfigure desk clamp




3. Post mount configuration




4. Bolt through - Drill Hole


5. Bolt Pole to work surface



6. Install VESA monitor head




7. Mounting Monitor




7.2 OPTIONAL SECURITY SCREW

Ensure the Monitor is supported, then loosen the Monitor head screw with the 5mm Allen Key and tilt screen up before installing the M4 x 16mm Security Screw into the Security Screw hole




8. Unlock/Lock Arm Rotation (Note: Focus Micro comes assembled in the "Locked" Position.)




Lock

If you have unlocked your Focus Micro Arm, but wish to fix rotation around the Pole, you will need to lock the arm


Step 1: Ensure the hole for the Grub Screw in the Micro Arm is lined up with the centre of the Slot in the Pole




9. Adjusting Height




10. Cable Management



11. Insert Cable Stops



12. Adjusting the Display Bracket





No portion of this document or any artwork contained herein should be reproduced in any way without the express written consent of Atdec Pty Ltd. Due to continuing product development, the manufacturer reserves the right to alter specifications without notice. ©20191024A