



Wall Direct Monitor Mount






IMPORTANT INFORMATION

- ! Please ensure this product is installed as per these installation instructions.
- ! This product is compatible with the range of AF Poles and arms.
- ! The manufacturer accepts no responsibility for incorrect installation.
- ! Curved monitors, deep devices (such as all-in-one PCs) and offset VESA locations exert additional leverage that can exceed the capacity of the mount even though the monitor weight may be within the stated range. Please contact Atdec if you would like further information.


1. Disassemble

1.1 Using the supplied allen key, remove the bottom screw 1.2 Seperate the two components


2. Attach base to wall




3. Re-assemble




4. Install VESA monitor head



5. Mounting Monitor



6. Adjusting the Display Bracket





No portion of this document or any artwork contained herein should be reproduced in any way without the express written consent of Atdec Pty Ltd. Due to continuing product development, the manufacturer reserves the right to alter specifications without notice. ©20191024A