


Installation Guide AWMS-BT40

Post Mounted Heavy Duty Monitor Mount






IMPORTANT INFORMATION


- ! Product should only be assembled and used as per these installation instructions.
- ! The manufacturer accepts no responsibility for incorrect installation.
- ! Each bracket supports a maximum weight as per above capacity specification.
- ! Avoid applying downward load to corners of display.
- ! Product must only be installed on a solid work surface capable of supporting the weight of all equipment being mounted.
- ! This product is not suitable for outdoor use.
- ! Do not use this product for mobile applications.
- ! VESA mounted accessories (such as mini PC brackets and mounts), and offset VESA locations exert additional leverage that can exceed the capacity of the mount even though the monitor weight may be within the stated range. Please contact Atdec if you would like further information.
- ! WARNING! Death or serious injury may occur if a child climbs on or tips product.

1. Attach post to fixing (fixing sold separately)




2. Attach VESA plate to display


NOTE: Some displays require the use of a VESA adapter before attaching the VESA plate. This VESA adapter may ship in the box with the display. Consult your display's installation guide for further information.




3. Slide bracket onto post




4. Set height




5. Attach display



6. Set tilt




7. Fine adjustment



7.1 To correct horizontal angle of display +/- 3 °:

Turn a single fine tune adjustment knob to adjust angle of screen.


Micro adjustment - Levelling +/- 3°



7.2 To fine tune height without removing screen +/-6mm (1/4"):

Turn both fine tune adjustment knobs - alternating sides a few rotations at a time.

Micro adjustment - Fine tune height



8. Cable management

