


# 10/100/1000 Mbps VDSL2 Ethernet Extender Kit - 1km

#### Product ID

**VDSL-LAN-EXTENDER-1G** 



Component		Function		
1	DIP Switches	<ul> <li>Set the Mode or change settings on the VDSL Extenders</li> <li>Refer to DIP Switch Chart</li> </ul>		
2	LAN Port	Connect to an RJ45 Port on Local and Remote     Equipment		
3	LAN Status LEDs	Refer to the <b>LED Chart</b>		
4	VDSL2 Status LEDS	Refer to the <b>LED Chart</b>		
5	VDSL2 Port	<ul> <li>Use a RJ45 or RJ11 Cable to connect the Local and Remote VDSL Extenders together</li> </ul>		
6	Power Input Port	<ul><li>Connect the included Power Adapter</li><li>Located on the rear of each VDSL Extender</li></ul>		

### **Product Information**

For the latest drivers/software, technical specifications, and declarations of conformance, please visit: www.StarTech.com/VDSL-LAN-EXTENDER-1G

## Requirements

- Ethernet Device x 2
- RJ45 Ethernet Cables x 2
- RJ45 or RJ11 Cable x 1

## **Package Contents**

- VDSL Extender x 2
- Mounting Bracket Kits x 2
- Power Supply x 2
- Ouick-Start Guide x 1

### Installation

## (Optional) Mounting the VDSL Extender

**Note:** Before mounting the **VDSL Extender** make sure that the surface you are mounting to is strong enough to support the **VDSL Extender**. It is recommended that the **VDSL Extender** is mounted on a wall stud to provide the correct support.

- 1. Determine the Mounting Surface for the Local and Remote VDSL Extender.
- Place the VDSL Extenders upside down to expose the Mounting Bracket Holes on the VDSL Extenders. Align the Holes in the Mounting Brackets with the Holes on the bottom of the VDSL Extenders.
- 3. Insert four Screws through each Mounting Bracket and into the VDSL Extender.
- 4. Tighten each **Screw** using a **Phillips Head Screwdriver**.
- 5. Mount the **VDSL Extender** to the desired **Mounting Surface** using the appropriate **Mounting Hardware** (e.g. Wood Screws).

### Install the VDSL Extender Kit

- 1. Position a **VDSL Extender** in each of the locations, local and remote.
- 2. Using DIP Switch 1, ensure that one VDSL Extender is in Master Mode (CO), and the other is in Remote Mode (RT).

**Note:** If the DIP switches need to be adjusted after the initial setup, both VDSL Extenders must be powered off before changing the DIP switch settings.

- Plug in an RJ45 Ethernet Cable from the LAN Port on the local VDSL Extender to an Ethernet Port on the local Ethernet Device.
- 4. Plug in an **RJ45 Ethernet Cable** from the **LAN Port** on the remote **VDSL Extender** to an **Ethernet Port** on the remote **Ethernet Device**.
- 5. Plug in a RJ45 or RJ11 Cable from the VDSL2 Port of the local VDSL Extender, to the VDSL2 Port of the remote VDSL Extender.
- 6. Connect the included Power Adapters to each of the VDSL Extenders.

#### **LED Chart**

LED	Colour	Blink	On	Off	
PWR	Green	N/A	Powered On	Powered Off	
RT	Green	N/A	RT (Remote)	CO (Master)	
LNK	Green	Slow: Idle Fast: Training	VDSL2 Link Up	VDSL2 Link Down	
10	Green	Data Activity	10Mbps	Link Down	
100	Green	Data Activity	100Mbps	Link Down	
1000	Green	Data Activity	1000Mbps	Link Down	

## **VDSL2 Port Pinout**

Pin	Description		
1	N/A		
2	N/A		
3	N/A		
4	Analog Input/Output		
5	Analog Input/Output		
6	6 N/A		
7	N/A		
8	N/A		

# Regulatory Compliance FCC - Part 15

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by StarTech.com could void the user's authority to operate the equipment.

#### **Industry Canada Statement**

This Class A digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe [A] est conforme à la norme NMB-003 du Canada.

CAN ICES-3 (A)/NMB-3(A)

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

(1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

(1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

### **DIP Switches**

**Note:** The VDSL Extender that is set to Remote mode will always follow the settings set on the Master VDSL Extender. When set to Remote Mode, DIP Switches 2, 3, and 4 have no function

	no tunction.							
No	CO DIP Switch	Symmetrical/ Asymmetrical	G.INP/ Interleaved Mode	SNR High/Low	Max Line Rate US/DS (Mbps)			
1	1 2 3 4 60	Symmetrical	G.INP	High	146/162			
2	1 2 1 1 6	Symmetrical	G.INP	Low	152/162			
3	1 2 1 4 6	Symmetrical	Interleaved	High	139/151			
4	1 1 1 4	Symmetrical	Interleaved	Low	148/151			
5	1 2 3 4 0	Asymmetrical	G.INP	High	66/341			
6	1 7 1 6	Asymmetrical	G.INP	Low	66/341			
7	1 1 1 6	Asymmetrical	Interleaved	High	63/329			
8	1 2 3 4 4	Asymmetrical	Interleaved	Low	65/328			

#### **Warranty Information**

This product is backed by a two year warranty.

For further information on product warranty terms and conditions, please refer to www.startech.com/warranty.

#### **Limitation of Liability**

In no event shall the liability of StarTech.com Ltd. and StarTech.com USA LLP (or their officers, directors, employees or agents) for any damages (whether direct or indirect, special, punitive, incidental, consequential, or otherwise), loss of profits, loss of business, or any pecuniary loss, arising out of or related to the use of the product exceed the actual price paid for the product. Some states do not allow the exclusion or limitation of incidental or consequential damages. If such laws apply, the limitations or exclusions contained in this statement may not apply to you.

# Use of Trademarks, Registered Trademarks, and other Protected Names and Symbols

This manual may make reference to trademarks, registered trademarks, and other protected names and/or symbols of third-party companies not related in any way to StarTech.com. Where they occur these references are for illustrative purposes only and do not represent an endorsement of a product or service by StarTech.com, or an endorsement of the product(s) to which this manual applies by the third-party company in question. StarTech.com hereby acknowledges that all trademarks, registered trademarks, service marks, and other protected names and/or symbols contained in this manual and related documents are the property of their respective holders.

StarTech.com Ltd. 45 Artisans Cres London, Ontario N5V 5E9 Canada StarTech.com LLP 4490 South Hamilton Road Groveport, Ohio 43125 U.S.A.

StarTech.com Ltd.
Unit B, Pinnacle 15
Gowerton Rd,
Brackmills
Northampton
NN4 7BW
United Kingdom

StarTech.com Ltd. Siriusdreef 17-27 2132 WT Hoofddorp The Netherlands FR: startech.com/fr DE: startech.com/de ES: startech.com/es NL: startech.com/nl IT: startech.com/ip